

## 4 in 1 Digital Thermostat RF

Models VS20WRF and VS20BRF  
VS10WRF and VS10BRF



INSTALLER / USER MANUAL

## Contents

### Contents

Box contents  
Introduction  
Product Compliance  
System options overview  
Installation  
Parameter Settings  
Error Codes  
User Guide  
Installers notes  
Warranty

### Box Contents



1 x Installer / User manual

### Icons used in this manual:



Safety



Important info



Your benefit

For latest PDF installation  
guide please go to  
[www.salus-controls.com](http://www.salus-controls.com)



4x AAA Batteries



Fixing screws



VS10WRF



VS20BRF

## Product Compliance & Safety Information

### INTRODUCTION

Thank you for purchasing the SALUS 4 in 1 room thermostat it must be used with the CO10RF Zigbee Coordinator. The Zigbee coordinator allows communication with other devices in the iT600 RF system range. Other Zigbee devices include wiring centre, system receiver & TRV.

### iT600RF Range



### Product Compliance

This product is CE compliant and meets the following EC Directives Electro-Magnetic Compatibility directive 2004/108/EC  
Low voltage Directive 2006/95/EC



### Safety Information

Use in accordance with the regulations  
The SALUS VS10/20RF is to be used for room control of heating and hot water systems inside the house.

We hope you enjoy this product...

## Product Compliance & Safety Information

These instructions are applicable to the SALUS model stated on the front cover of this manual only.



### Warning

This product must be fitted by a competent person, and installation must comply with the guidance, standards and regulations applicable to the city, country or state where the product is installed. Failure to comply with the requirements of the relevant guidance, standards and regulations could lead to injury, death or prosecution.



### Sources of danger

The thermostat must be disconnected from mains supply before removing the cover.



### Emergency

Switch off the voltage to the individual thermostat wiring centre or complete system.



### 230V AC



### Warning

Always isolate the AC Mains supply before installing or working on any components that require 230 VAC 50Hz supply.



### Installer parameter settings


The SALUS VS10 and VS20 are equipped with installer parameter section (see page 57) this must only be entered by the installer or competent person. Changing these parameters can have a serious effect on your heating system



### For the installer

Please enter any parameter changes in the installer notes section (pages 90)

## System Overview - Configuration Options



\* Grouping and timer option only available when used with wiring centre.

## System Overview - Configuration Options

### Programmable Room Thermostat (PRT)

When configured for PRT (see page 32) it mainly works by itself and allows the user to have separate Time and Temperature control of each zone on the wiring centre, radiator valve or system receiver. Features like Vacation, Party frost mode have to set on each individual thermostat. All PRTs paired with a wiring centre can also use the global heat/cool changeover function if the your system supports this. This is achieved by using the heat/cool changeover connection on the wiring centre (see note 8 on wiring centre guide).

### Group Control Thermostat

When configured for a PRT (see page 32) it can operate as a group control thermostat by assigning a group when pairing with the wiring centre this allows central control of up to 7 group thermostats see below, there can be a maximum of 2 groups per 8 zone wiring centre. Permanent temperature override, Holiday, Party, Frost modes, can be selected centrally from the Group Control Thermostat. Holiday will also be applied to a timer if applicable. The group thermostats can be also globally changed from heating to cooling thermostats if you system supports this by using the switched input connection on the WC (see note 8 on the wiring centre guide).

### Group Thermostat

When configured as a digital thermostat and assigning a group when pairing with a WC it can operate as a group thermostat (see page 31), in group mode the group thermostat will follow the time schedule and any override modes of the group control thermostat. At least one group control thermostat is required for grouping see above. The group thermostat can have its own programmed temperatures, manual override and also be removed from the group temporarily or permanently.

### Timer

When configured to timer (see page 32) the unit will operate as a timer with no temp control. This can be used for hot water control. The timer will also follow Holiday mode from the group control thermostat if applicable.

## System Overview - Zigbee Coordinator



Zigbee coordinator required for communication between these devices.



KL10RF



VS10 / VS20RF



C010RF



RX10RF




TRV10RF

## System Overview - iT600 System



The thermostat can communicate with all these iT600 devices



System Receiver configured to one room receiver RX2.  
Refer to system receiver RX10RF.



System Receiver configured to boiler receiver.  
Refer to system receiver manual RX10RF.

Max 3 TRV per thermostat



## System Overview - Hot Water Option



When the unit is configured as a hot water timer (see page 32) there are two methods of connecting the cylinder thermostat.

Unit configured to  
Hot Water Timer.



Cylinder thermostat options


- 1 Connected direct to WC (Default)
- 2 Connected direct to VS10/20RF (requires additional parameter change. See page 57)

## System Overview - Hot Water Option



For convenience there is a unique built in option allowing the cylinder thermostat to be connected to either the HW Timer or Wiring Centre.

### 1 Connected direct to WC (Default)



### 2 Connected direct to VS10RF/20RF (requires additional parameter change see page 37)







Please refer to note 1 on Wiring Centre guide and pages 15 and 20 for more information.

## Installation – Thermostat Mounting



### Mounting position and installation

To ensure trouble free operation and efficient control, the unit is best positioned in a draft free area and at 130cm from the floor. Do not position the thermostat near any heat source, behind curtains, direct sunlight or an area of high humidity.




Not to be positioned on an exterior wall.

INSTALLATION

## Installation – Thermostat Mounting VS20WRF



Carefully remove the front housing.




## Installation – Terminal Connections VS20WRF

### Understanding your terminal connections

INSTALLATION

Rear of unit



#### Sensor Terminals

Can be used for external AIR, Floor sensor when configured as thermostat. Can also be used for Cylinder thermostat when configured for HW. See page 57.

## Installation – Thermostat External Sensor VS20WRF




SALUS External sensor (Sold separately)




**Note:** If you are using an external sensor, the unit has to be configured for External Air Sensor or Floor Protection Sensor please see device parameter setting page 57.


## Installation – Hot Water Timer Cylinder Thermostat VS20WRF




Cylinder  
thermostat  
SALUS CT100



WC connected cylinder thermostat (Default)



Link must be fitted



HW Timer connected cylinder thermostat



**Note:** The unit can be configured for Cylinder thermostat or connected to the Hot Water Timer. Please see device parameters page 57. For additional Wiring Centre information refer to note 1 on Wiring Centre guide.

## Installation – Thermostat Mounting VS20WRF

Once you have connected your choice of external sensor (if applicable)

1



2



3



Insert batteries

4




**Note:** Please proceed to page 23




## Installation – Thermostat Mounting VS10WRF

INSTALLATION




Carefully remove the front housing.



## Installation – Terminal Connections VS10WRF

### Understanding your terminal connections




**Power Terminals 230 Vac**  
Used for supplying power to the unit. 230V supply can be sourced from the wiring centre or any convenient source.



**Sensor Terminals**  
Can be used for external AIR, Floor sensor when configured as thermostat. Can also be used for Cylinder thermostat when configured for HW.

## Installation – Thermostat External Sensor VS10WRF

INSTALLATION




SALUS External sensor (Sold separately)




**Note:** If you are using an external sensor, the unit has to be configured for External Air Sensor or Floor Protection Sensor please see device parameter setting page 57.

## Installation – Hot Water Timer Cylinder Thermostat VS10WRF



WC connected cylinder thermostat (Default)



HW Timer connected cylinder thermostat



**Note:** The unit can be configured for Cylinder thermostat or connected to the Hot Water Timer. Please see device parameters page 57. For additional Wiring Centre information refer to note 1 on Wiring Centre guide.

## Installation – Thermostat Mounting VS10RF

INSTALLATION



Check that the wiring is completed for:

**1**

Power Terminals

**2**

Sensor Terminals (if applicable)



You are ready to secure the rear housing to the wall box



Please use the screws provided



Ensure the orientation arrow is pointing upwards.




## Installation – Thermostat Mounting

**i** Fit the front housing to the rear housing

**i** Ensure the pin connections are aligned
















**1** Align the front housing at the bottom edge.









**2** Lightly press until you hear a positive click.

## Installation – LCD Graphics

ICON	FUNCTION
	<b>BOX</b> means to select the mode e.g.  means the current setpoint is Hi temp,  means the Hi temp is not selected.
	<b>Sunny:</b> Hi comfortable temperature.
	<b>Cloudy:</b> Middle comfortable temperature.
	<b>Moon:</b> Low comfortable temperature.
	<b>Programmable thermostat Program mode indicator:</b> Indicates program is running, Auto On or Auto Off. For group thermostat this indicates that it is a member of a group.
	<b>Party indicator:</b> When Party mode is active.
	<b>Vacation indicator:</b> When Vacation mode is active
	<b>Frost protection indicator:</b> Frost protection is active, not available in cooling mode (if applicable)
	<b>RF Transmission is active</b>
	<b>Group 1 Control Thermostat</b>
	<b>Group 2 Control Thermostat</b>
	<b>Group 1 Thermostat</b>
	<b>Group 2 Thermostat</b>








## Installation – LCD Graphics

ICON	FUNCTION
	<b>Heat indicator:</b> Indicates heat is required.
	<b>Cool mode indicator:</b> Indicates cooling is required (if applicable)
	<b>Temperature indicator:</b> Display the room temperature. Display the set-temp. Also used to show the other information.
	<b>Temporary manual override indicator:</b> If the set temperature is changed when in program mode, the hand will appear until the next program start time.
	<b>Programs number indicator:</b> In AUTO program mode or Temporary override is running, it means the current program running.
	<b>Day indication:</b> 1 = Monday







## Installation – LCD Graphics








INSTALLATION

ICON	FUNCTION
	<b>Hot Water (HW) indicator:</b> Unit has been configured for HW Timer.
	<b>Hot Water (HW) indicator:</b> Indicates that there is Hot Water demand.
	<b>HW Program mode indicator:</b> Indicates program is running.
	<b>HW Mode indicator:</b> Mode for 1 period of HW a day, from Program 1 ON to Program 3 OFF.
	<b>HW Mode indicator:</b> Indicates continuously On.
	<b>HW Mode indicator:</b> Indicates continuously Off.
	<b>HW Mode indicator:</b> Indicates Boost +1hr override.

## Installation – LCD Graphics

ICON	FUNCTION
	<b>Floor sensor probe indicator</b> Show only when Air + Floor sensor is connected.
	<b>Low battery indicator:</b> Batteries need to be replaced.
	<b>Setting indicator:</b> Indicate the unit is in setting mode when program setting. Indicate the manual mode.
	<b>Keylock indicator:</b> Shows that keys are inactive.

## Installation – User Interface

KEY	FUNCTION
 OR 	<ol style="list-style-type: none"> <li>1. Increase or decrease setpoint temperature.</li> <li>2. Increase or decrease Day, Clock, Timer, Party, Holiday and Boost.</li> <li>3. Select installer parameter value.</li> </ol>
 OR 	<ol style="list-style-type: none"> <li>1. Mode selection.</li> <li>2. Long press to return to home display without saving.</li> <li>3. Short press to return to the previous screen when it is in user/installer setting mode.</li> </ol>
	<ol style="list-style-type: none"> <li>1. OK key: Short press to confirm selection.</li> <li>2. Long press to save and exit.</li> <li>3. Long press to enter the user settings.</li> </ol>
 LONG PRESS	Lock/Unlock
 LONG PRESS	Enter Installer parameter settings

## Installation - Graphics Key



Press once



Press x amount of times



Hold for five seconds



Flashing



Short press to back up




Short press to save and  
long press to save and exit



## Installation – First Power Up

INSTALLATION



## Installation - System Setup

### System setup checklist

- 1** The Zigbee coordinator must be in pairing mode.  
Before starting the pairing, make sure the light is flashing on the coordinator by holding the button for 5 seconds. For more information refer to the coordinator instruction manual.



- 2** The device that you intend to pair with must be ready to accept pairing.  
Please refer to pages 33-45 and the relevant device installation guides.

## Installation – System Parameters

You are now ready to configure the unit using the system parameter table below.



INSTALLATION

SX	FUNCTION	SYSTEM SETTING	DEFINITION	DEFAULT
S01	System Unit Type	0	Programmable Stat (PRT)	0
		1	Digital Thermostat	
		2	HW Timer	
S02	What does unit Communicate within the iT600 system	0*	It600 Wiring Centre*	0
		1	It600 radiator valve	
		2	System Receiver set for RX2	
		3**	System Receiver set to RX1**	



\*Grouping is available on the wiring centre only please refer to page 6. Additionally you must have a PRT per group for grouping to operate. Two groups are the maximum allowed per wiring centre.

\*\* This setting is used when there is a system receiver only in the system. If there is a system receiver set to RX1 used along with wiring centre, radiator valves and system receiver set to RX2 then RX1 will communicate automatically to the thermostat connected to these other devices.

## Installation - System Setup

### Selecting what type of unit



Use or to select the type of unit. After selection has been made, press to confirm.



Programmable Stat (PRT)

Digital Thermostat

HW Timer

### Selecting what unit to pair with



Use or to select the type of unit to pair with.



Wiring  
Centre.  
Page 33



Radiator Valve.  
Page 37



System Receiver  
Configured RX2.  
Page 41



System Receiver  
Only configure RX1.  
Page 44



## Installation - Pairing with Wiring Centre



Wiring  
Centre

PAIRING  
WITH WC




### Checklist

- 1 The Zigbee coordinator must be in pairing mode.
- 2 Ensure the wiring centre and optional system receiver (Configured to RX1) for remote boiler switch are powered up. Note: The wiring centre and system receivers will automatically join Zigbee network when powered up and the Zigbee coordinator is in pair mode. Red LED on Wiring Centre and RX1 will go steady when the devices have joined the Zigbee network.




- 3 If more than one wiring centre is in the system, establish and note the wiring centre number by pressing the network key for 1 second. The wiring centre number will flash.


## Installation - Pairing with Wiring Centre



## Installation - Pairing with Wiring Centre



## Installation - Testing the pairing with the RF WC



If you are using the optional system receiver configured to RX1 please check that the green light goes on when the temperature is raised and off when reduced.



If pairing for your system is complete, please take the coordinator out of pair mode. Press for 5 seconds and light will stop flashing.



## Installation - Pairing the Radiator Valve(s)



Radiator  
Valves




PAIRING  
WITH TRV


### Checklist

- 1 The Zigbee coordinator must be in pairing mode.
- 2 Ensure that the radiator valves are in pairing mode (Refer to TRV10RF manual). A maximum of 3 radiator valves can be used with 1 thermostat. Pairing of radiator valve. Please pair TRV's on a room by room basis.
- 3 If you are using the optional system receiver configured to RX1 for remote boiler switching. Ensure this has been powered up and the red flashing LED has gone steady.


## Installation - Pairing with Radiator Valve



## Installation - Pairing with the Radiator Valve



## Installation - Testing RF Pairing



If you are using the optional system receiver configured to RX1 please check that the green light goes on when the temperature is raised and off when reduced.



If pairing for your system is complete, please take the coordinator out of pair mode. Press for 5 seconds and light will stop flashing.





## Installation - Pairing with System Receiver RX2



Refer to system receiver manual.

System Receiver Configured to RX2 single room receiver.




### Checklist

- 1 The coordinator must be in pairing mode.
- 2 The system receiver (RX2) is powered up and the red LED is steady. Refer to RX10RF manual.
- 3 If you are using the optional system receiver configured to RX1 for remote boiler switching. Ensure this has been powered up and the red flashing LED has gone steady. Refer to RX10RF manual.




PAIRING  
WITH RX2

## Installation - Pairing with System Receiver RX2



## Installation - Testing Pairing with System Receiver RX2



## Installation - Pairing with System Receiver RX1 only

Used if system receiver is used on its own.



System Receiver configured to boiler receiver RX1. Refer to system receiver manual.


### Checklist

- 1 The coordinator must be in pairing mode.
- 2 The system receiver (Configured to RX1) is powered up and the red LED is steady. The system receiver will auto join the Zigbee network on power up when the Zigbee coordinator is in pairing mode.





**This configuration option is applicable if there is only a system receiver RX1 in the system.**

## Installation - Pairing with System Receiver RX1 only



## Installation - Testing Pairing with System Receiver RX1 only




 If pairing for your system is complete, please take the coordinator out of pair mode. Press for 5 seconds and light will stop flashing.




## Installation - Modifying System Parameters

If you have made an error or need to change your system parameters please follow steps below. This should only be done by your installer.



INSTALLATION

## Installation - Modifying System Parameters





## Installation - Checking System Configuration

INSTALLATION



To check that the complete system is communicating and has been configured correctly, you can use identify mode.




Using identify from the coordinator will show all products that are connected to your system.



Press for 1 second to activate identify mode.



Press again for 1 second to cancel identify. Identify mode will time out after 10 minutes.



## Installation - Checking System Configuration



To check that the relevant system is communicating and has been configured correctly, you can use identify mode.



Please follow step 1 on page 47. When in identify mode all receivers and the coordinator related to the individual PRT will flash.



PRT

System has no grouping



Press tick to cancel identify. Identify mode will time out after 10 minutes.



PRT



PRT



PRT



PRT



PRT



## Installation - Checking System Configuration



To check that the relevant system is communicating and has been configured correctly, you can use identify mode.




Please follow step 1 on page 47. When in identify mode all receivers, group thermostats and the coordinator will flash.

INSTALLATION




Group Control Thermostat



System has grouping



Press tick to cancel identify. Identify mode will time out after 10 minutes.



Group Control Thermostat

Group Thermostat

Group Thermostat

Group Thermostat

PRT

## Installation - Checking System Configuration



To check that the relevant system is communicating and has been configured correctly, you can use identify mode.



Please follow step 1 on page 47. When in identify mode all receivers, control group thermostat and the coordinator will flash.



Group Thermostat



System has grouping



Press tick to cancel identify. Identify mode will time out after 10 minutes.



Group Control Thermostat

Group Thermostat



Group Thermostat



Group Thermostat



PRT



## Installation - Checking System Configuration



To check that the complete system is communicating and has been configured correctly, you can use identify mode.



Using identify from the wiring centre will show all products that are connected to your wiring centre. Then wiring centre number will also be shown.


INSTALLATION



Press for 5 second to activate identify mode.



Press again for 1 second to cancel identify. Identify mode will time out after 10 minutes.



## Installation - Checking System Configuration



To check that the relevant system is communicating and has been configured correctly, you can use identify mode.



Please follow step 1 on page 47.  
When in identify mode all radiator valves, receivers and the coordinator related to the individual PRT will flash.



PRT



System has no grouping



Press tick to cancel identify.  
Identify mode will time out after 10 minutes.



PRT




PRT



PRT



PRT




## Installation - Replacing product



Before replacing any device it must be removed from the Zigbee network. Please ensure the Zigbee coordinator is also in pairing mode.

INSTALLATION

Deleting Wiring Centre from the network.



Press for 15 seconds to delete the wiring centre from the network.



All LED's will flash momentarily and then the wiring centre will be deleted from the network. All thermostats relating to the wiring centre will need to be reconfigured and paired with the new wiring centre.



If the wiring centre cannot be deleted as above, use the method below.



Please follow step 1 on page 47. Select password 46.



You are now ready to install your new wiring centre.



## Installation - Replacing product



Before replacing any device it must be removed from the Zigbee network. Please ensure the Zigbee coordinator is also in pairing mode.

Deleting thermostat from the network.




Please follow step 1 on page 47. Select password 48.



Your thermostat will now be deleted from the network. You are now ready to install your new thermostat. Please note password 48 can also be used to delete other devices that are offline.




Note: If replacing a thermostat connected to the wiring centre, you can use the replacement method.



The unit previously connected to the wiring centre will be replaced.



## Installation - Device parameters



Device parameters will follow system parameters on first power up. If you need to change device parameters follow the steps below.

Please note, your system parameters will be shown first but cannot be edited in this section. To change the system parameters please refer to page 47.

INSTALLATION

## Installation - Device Parameters

DX	FUNCTION	SYSTEM SETTING	DEFINITION	DEFAULT
D01	Heating Control	0	Pulse Width Modulation	0
		1	On-Off 0.5 Deg C +/- 0.25 Deg C	
		2	On-Off 1.0 Deg C +/- 0.5 Deg C	
D02	Room Temperature Offset	-3.0 to 3.0 Deg C	Temperature Offset from Measured Temperature to Compensate for any error	0 Deg C
D03	Sensor probe or Cylinder thermostat connection	0	Sensor/Cyl stat not Connected	0
		1	Sensor/Cyl stat Connected	
D04	Sensor probe used as air sensor or floor sensor	0	D03 must be set to 1 then external sensor be used as Air sensor. There will be no internal temp measurement	0
		1	D03 must be set to 1 then external sensor used for floor protection. Internal temp is measured by stat	
D05	Cooling Control	1	On-Off 0.5 Deg C +/- 0.25 Deg C	2
		2	On-Off 1.0 Deg C +/- 0.5 Deg C	
D06	Actuator type	0	NO Normally Open	1
		1	NC Normally Closed	
D07	Valve protection	0	Disable	1
		1	Enable	

## Installation - Device Parameters continued

INSTALLATION

DX	FUNCTION	SYSTEM SETTING	DEFINITION	DEFAULT
D08	Frost Set point Temperature	5-17 Deg C	Required Temperature for frost protection and holiday mode	5 Deg
D09	Hour Format	0	12	1
		1	24	
D10	N/A	N/A	N/A	N/A
D11	Daylight Saving Time (DST)	0	OFF	1
		1	ON	
D12	Heating Set point Limit	5-35 Deg C	Maximum temp that can be set for heating	35 Deg C
D13	Cooling Set point Limit	5-40 Deg C	Maximum temp that can be set for Cooling	5 Deg C
D14	Floor sensor High Limit Temperature	6-45 Deg C	Output relay will be switched off when temp is reached for floor protection	27 Deg C
D15	Floor sensor Low Limit Temperature	6-45 Deg C	Output relay will be switched on when temp is reached for floor protection	10 Deg C
D16	Floor sensor Limit for cooling	6-45 Deg C	Output relay will be switched off when temp is reached for floor protection	6 Deg C

## Installation - Error Codes

Error Code	Prog	Non-Prog	HW
01	Comm Connection link failure	Comm Connection link failure	Comm Connection link failure
02	Comm Connection link failure	Comm Connection link failure	Comm Connection link failure
03	Floor sensor open	Floor sensor open	-
04	Floor sensor short	Floor sensor short	-
05	Prog/Non-prog/HW thermostat lost link with Coordinator (Displayed on related Thermostat) Comm Connection link failure	Prog/Non-prog/HW thermostat lost link with Coordinator (Displayed on related Thermostat) Comm Connection link failure	HW lost link with Coordinator
06	Prog/Non-prog/HW thermostat lost link with WC (Displayed on related Thermostat)	Prog/Non-prog/HW thermostat lost link with WC (Displayed on related Thermostat)	HW lost link with WC
07	Prog/Non-prog Thermostat lost link with TRV (Displayed on related Thermostat)	Prog/Non-prog Thermostat lost link with TRV (Displayed on related Thermostat)	-
08	Prog/Non-prog Thermostat lost link with Receiver RX 1 (Displayed on related Thermostat)	Prog/Non-prog Thermostat lost link with Receiver RX 1 (Displayed on related Thermostat)	-
09	Prog/Non-prog Thermostat lost link with Receiver RX 2 (Displayed on related Thermostat)	Prog/Non-prog Thermostat lost link with Receiver RX 2 (Displayed on related Thermostat)	-



If there is more than 1 error, then on Error page, press UP to show other error codes.

e.g. Err 03 05 ==> 3 errors Error code 05 ( 1st one )

Press Up to show Err 03 08 ==> 3 errors Error code 08 ( 2nd one )

Press Up again to show Err 03 09 ==> 3 errors Error code 09 ( 3rd one )

Press Up again to show Err 03 05 again.....

Press OK to exit Error page back to Home display.



## Installation - Error Codes

Error Code	Prog	Non-Prog	HW
10	WC lost link with hot water timer (Displayed on all relevant thermostats and also hot water timer)	Comm Connection link failure (Displayed on all relevant thermostats and also hot water timer)	Comm Connection link failure (Displayed on all relevant thermostats and also hot water timer)
11-18	WC lost link with zone 11=Zone 1, 12=Zone 2 etc Displayed on all connected thermostats	Comm Connection link failure 11=Zone 1, 12=Zone 2 etc Displayed on all connected thermostats	-
19	WC lost link with coordinator (Displayed on all connected thermostats and hot water timer)	WC lost link with coordinator (Displayed on all connected thermostats and hot water timer)	WC lost link with coordinator (Displayed on all connected thermostats and hot water timer)
20	WC lost link with receiver RX1 (Displayed on all connected thermostats and hot water timer)	WC lost link with receiver RX1 (Displayed on all connected thermostats and hot water timer)	WC lost link with receiver RX1 (Displayed on all connected thermostats and hot water timer)
21	TRV lost link with coordinator (Displayed on all connected thermostats)	TRV lost link with coordinator (Displayed on all connected thermostats)	-
22	TRV low battery (Displayed on all connected thermostats)	TRV low battery (Displayed on all connected thermostats)	-
23	Invalid TRV	Invalid TRV	-
24	Unit is rejected by wiring centre	Unit is rejected by wiring centre	-


INSTALLATION

## Installation - Technical Detail

<b>Model</b>	VS10RF / VS20RF
<b>Type</b>	Electronic programmable room thermostat, digital room thermostat and hot water RF
<b>Programming Modes</b>	User selectable for 5/2, ALL and Individual day options
<b>Program Number</b>	1-6 Selectable
<b>Modes</b>	Party, Vacation, Program and Frost
<b>Override</b>	Permanent and temporary
<b>Frost Protection</b>	5°C Adjustable
<b>Power Source</b>	230V AC 50Hz VS10RF - 4 x AAA VS20RF
<b>Temperature Scale</b>	5 to 35°C, tolerance 0.5°C
<b>Heat/Cool</b>	Global changeover using communication bus and external input to the wiring centre
<b>Sensor</b>	Air or floor protection. Cylinder thermostat when configured for hot water timer.
<b>Device Parameters</b>	See page 57
<b>Operating Temperature</b>	0 to 50°C
<b>Storage Temperature</b>	-20 to 60°C
<b>Frequency</b>	2.4HGz Zigbee


## User Guide - Setting time and date

PRT and Group Control Thermostat



## User Guide - Setting time and date


PRT and Group Control Thermostat





## User Guide - Setting time and date

PRT and Group Control Thermostat



## User Guide - Understanding Temperature Levels Heating

PRT, Group Control Thermostat and Group Thermostat



Highest Temperature typically used for early morning and early evening.

**Typically 21 Deg C**



Mid Temperature typically used for times of day when you are active around the home

**Typically 19 Deg C**



Lower Temperature typically used for unoccupied or sleep times. **Typically 17 Deg C for UFH or 15 Deg C for radiators**



Frost Temperature typically used for Periods of long absence or holidays. **Typically 5 Deg**



Your thermostat comes preset for the above temperatures. These can be adjusted please see page 71

## User Guide - Understanding Temperature Levels Cooling

PRT, Group Control Thermostat and Group Thermostat



Cooling is only available if your system supports this and the relevant configurations and connections have been made to the unit.



Occupied Temperature. Typically 22°C



Unoccupied Temperature Typically 40°C

This avoids cooling being active when the property is unoccupied.



Evening Temperature Typically 24°C




Your thermostat comes preset for the above temperatures. These can be adjusted please see page 71


## User Guide - Default Heating Schedule

### PRT and Group Control Thermostat

Monday to Friday






Saturday to Sunday



If using grouping, the schedule from the group control thermostat will be applied to group members.

### PRT and Group Control Thermostat

	22						
	40						
	24						
		12.00	7.00	9.00		17.00	23.00

 22							
 40							
 24							
	12.00	8.00	9.00		17.00		23.00

If using grouping, the schedule from the group control thermostat will be applied to group members.

## User Guide - Graphics Key



Press once



Press x amount of times



Hold for five seconds



Flashing



Short press to back up




Short press to save and  
long press to save and exit



## User Guide - Setting required temp levels

### PRT, Group Control Thermostat and Group Thermostat

Setting the low temperature



## User Guide - Setting required temp levels


### PRT, Group Control Thermostat and Group Thermostat



Repeat for




Move back to **A** once temperature levels have been chosen.








## User Guide – Setting the Temperature Schedule

 If using grouping, the schedule from the group control thermostat will be applied to group members.

 Use right and left arrows to select the day of the programs.



## User Guide – Setting the Temperature Schedule



## User Guide – Setting the Temperature Schedule









Repeat through to program 4.  
If you require a 5th or 6th program enter  
a time and select your temperature



To remove a program out set the time to --:--.



When you set the    temperature the schedule will respond  
to those temperatures see page 71 on how to change   

## User Guide - Temporary Override

### PRT, Group Control Thermostat and Group Thermostat



Use the up or down arrow key to view your program set temperature.



The temporary override is applicable to the thermostat being changed only.



Temporary override allows you to increase the temperature or decrease it to the desired setting until it reverts back on the next program time.




Use the up or down arrow key to adjust the temperature to the setting you desire.



## User Guide - Temporary Override

### PRT, Group Control Thermostat and Group Thermostat




 To cancel temporary override press < or >  
See below.



## User Guide - Permanent Override

### PRT and Group Control Thermostat

Setting permanent low temperature



Permanent override in a control group thermostat will also affect the group thermostats unless they are removed from the group. See page 64.




To cancel permanent override select **A**  
See below.

Repeat for



if required




## User Guide - Party Mode

### PRT and Group Control Thermostat


The party mode is an option that enables temperature for a period of time you select up to 9hr 50min.

Party Mode set in a Control Group Thermostat will also affect group thermostats unless they are removed from the group. See page 64.



## User Guide - Holiday Mode


Holiday set in a Control Group Thermostat will also affect group thermostats unless they are removed from the group. See page 82.









## User Guide - Frost Protection

Frost protection set in a Control Group Thermostat will also affect group thermostats unless they are removed from the group.  
See page 82.





## User Guide - Group Thermostat Overview

When a group thermostat is in **A** and the group control thermostat is in  or  then the group thermostat will follow this mode.  or  will be displayed.



When a group thermostat is in **A** it will follow the mode status of the group control thermostat.

The group thermostat has now left the group and is in permanent . To adjust the set temperature, please refer to page 71.


The group thermostat has now left the group and is in permanent . To adjust the set temperature, please refer to page 71.

## User Guide - Group Thermostat Overview




The group thermostat has now left the group and is in permanent . To adjust the set temperature, please refer to page 71.




The group thermostat has now left the group and is in permanent . To adjust the set temperature, please refer to page 71.



The group thermostat has been returned to  it will follow the mode status of the group control thermostat.


## User Guide - Hot Water (Optional) Mode Selection

### Mode selection




When **A** is selected, the hot water timer will follow the program schedule. See page 86.



Hot water will follow Holiday mode from the group control thermostat.  will be displayed.

## User Guide - Hot Water Boost




## User Guide - Default Hot Water Schedule




Your hot water timer comes preset with the times below.  
These can be adjusted. See next page.


Monday to Friday




Saturday and Sunday




## User Guide - Setting Hot Water Times



## User Guide - Setting Hot Water Times







## Installer Notes

[illegible]

## Warranty

SALUS Controls warrants that this product will be free from any defect in materials or workmanship, and shall perform in accordance with its specification, for a period of five years from the date of installation. SALUS Controls sole liability for breach of this warranty will be (at its option) to repair or replace the defective product.

Customer Name: .....

Customer Address: .....

..... Post Code: .....

Tel No: ..... Email: .....

Engineers Company: .....

Tel No: ..... Email: .....

Installation Date: .....

Engineers Name: .....

Engineers Signature: .....

## **SALUS Controls plc**

SALUS House  
Dodworth Business Park South,  
Whinby Road,  
Dodworth, Barnsley S75 3SP, UK.

**SALES:** T: +44 (0) 1226 323961  
E: [sales@salus-tech.com](mailto:sales@salus-tech.com)

**TECHNICAL:** T: +44 (0) 1226 323961  
E: [tech@salus-tech.com](mailto:tech@salus-tech.com)

**[www.salus-controls.com](http://www.salus-controls.com)**



SALUS Controls is a member of the Computime Group

Maintaining a policy of continuous product development SALUS Controls plc reserve the right to change specification, design and materials of products listed in this brochure without prior notice.

**For PDF Installation guide please go to [www.salus-controls.com](http://www.salus-controls.com)**

00086/2 Issue Date: June 2014