### DELETING THE REPEATER FROM THE NETWORK





Press button on the Repeater for 15 seconds to delete it from the network.







The button colour changes to amber to indicate deletion.
At this point, you cannot cancel the procedure.




After you have deleted the repeater from the ZigBee network, it will need to be re-installed.

Also, if you delete the repeater, all the thermostats connected to the repeater will lose their connection to the network.

### WARRANTY

SALUS Controls warrants that this product will be free from any defect in materials or workmanship, and shall perform in accordance with its specification, for a period of five years from the date of installation. SALUS Controls sole liability for breach of this warranty will be (at its option) to repair or replace the defective product.



INSTALLER / USER MANUAL

### TECHNICAL DETAIL

Model	RE10RF
Туре	ZigBee Repeater
Function	ZigBee network repeater for iT600 system
Control	Open - Close the ZigBee network
Indication	Bi-Colour LED: RED - AMBER
User Interface	Single push button
Operating Temperature	0 to 45 °C
Storage Temperature	-20°C to 60°C
Frequency	2.4 GHz
Power Source	230V 50Hz via mains adaptor (supplied)
Approval	CE

#### SALUS Controls plc

SALUS House

Dodworth Business Park South, Whinby Road,

Dodworth, Barnsley S75 3SP, UK.

**SALES:** T: +44 (0) 1226 323961

E: sales@salus-tech.com

**TECHNICAL:** T: +44 (0) 1226 323961

E: tech@salus-tech.com

### www.salus-controls.com





SALUS Controls is a member of the Computime Group

Maintaining a policy of continuous product development, SALUS Controls plc reserves the right to change specification, design and materials of products listed in this brochure without prior notice.

For PDF Installation guide go to www.salus-controls.com

00086/2 Issue Date: DEC 2014

### Box Contents SYSTEM OVERVIEW

# SALUS 2gles from M 703 1179

1 x Installer / User manual





1 x EU Plug Adapter

For PDF Installation guide go to www.salus-controls.com

## $\bigcirc$ i

### Product Compliance

- Electro-Magnetic Compatibility directive 2004 / 108 / EC
- Low voltage Directive 2006/95/EC



### Warning

These instructions are applicable to the SALUS model stated on this instruction guide.

This product must be fitted by a competent person, and installation must comply with the guidance, standards and regulations applicable to the city, country or state where the product is installed. Failure to comply with the requirements of the relevant guidance, standards and regulations could lead to injury, death or prosecution.



#### Warning

Always isolate the AC Mains supply before installing or working on any components that require 230 VAC 50Hz supply.

We hope you enjoy this product...

# INTRODUCTION

If your iT600 system has more than 32 battery-powered devices, alongside the CO10RF ZigBee coordinator you must add an RE10RF ZigBee repeater. You must also add an RE10RF repeater if the battery-powered devices in your iT600 system are too far away from the mains-powered devices.




Refer to individual device manuals for more information.

The ZigBee repeater must be used with the iT600 RF range of products below:

INSTALLATION

#### iT600 System



### **INSTALLATION**



Press and hold the button on the Coordinator for five seconds to enter pairing mode. The LED flashes red.



Press and release the repeater button. The LED goes solid red to show it is connected to the network.



Plug in the coordinator as described in the Coordinator Instruction Manual. All device pairing is done through the coordinator.



Plug the repeater into the mains power. The button flashes red.



The system installation is now complete. Press and hold the button on the Coordinator for five seconds to close pairing mode. The LED goes solid red. Also refer to the coordinator and individual device manuals.

